

Assembly instructions

Guard rails from 1300.04 to 1300.09

Necessary tools :

- 1 Pop Rivet Pliers



Supplied spare parts :

- 1 guard rail 3 sides
- 4 pop rivets Ø4x8



1°) Install the guard rail on the trolley as shown above with the following procedures :

- Inclined the guard rail backwards and start by passing the back feet under the top tray
- Fold the guard rail in front of the trolley by opening the front sides in order to fix the lateral feet under the top tray



2°) Fix the guard rail on the trolley with the 4 supplied pop rivets with a pop rivet pliers

(Holes are under the steel tray under the polypropylene tray for fixing the guard rail)

Pop rivets